CRAFTBOT® FIRMWARE MANUAL UPDATE

Updating the firmware adds new function(s) and improves performance.

CAUTION!
NEVER turn OFF the computer or disconnect USB cable while updating the firmware.

1. Download CraftPrint® software from Craftunique® website:
   https://craftbot.com/craftware/

   Get CraftPrint

2. Install the CraftPrint® application on your computer.

3. Download the pr3Dator® firmware file from Craftunique website and extract the ZIP file on your computer. Please read the attached Release Notes.
   https://www.craftunique.com/firmware

4. Connect the printer to your computer with USB cable.

5. Open the CraftPrint program.

6. Select the „Load custom firmware from file” from „ … ” menu

7. Select and open the *.firmware file

8. On successful load you got message, click OK!

9. Open again the “…” menu and select Update CraftBot firmware from loaded file…

10. When asked please turn off the printer at least 5 seconds.

11. Turn back the printer and wait until the update finished

12. When the update finished, power cycle the printer once again. Check the pr3Dator firmware version on printer.

Update is done.