

PLEXIGLASS DOOR INSTALLATION MANUAL



Craft
Bot

INSTALLATION MANUAL

1. In the first step, remove the latch from the lock.



2. Then take the protective film off the adhesive strip located on the back of the front panel.



3. Place the front panel and the handle on the glass. Make sure that the hole on the glass falls behind the hole on the front panel.



4. Place the lock in the hole.



5. Now turn the door over the other side.



6. Put the shim on the screw, then thread the nut onto the screw.



7. Fasten the latch to the lock again with the screw. Check that you can open and close the lock easily.



8. Mount the hinges on the door. Arrange the hinges properly, then tighten the screws.



9. Put the other part of the hinge (which will be installed onto the CraftBot) on the upper hinge fixed to the door.



10. Fasten the door to the CraftBot. The gap between the upper edge of the door and the frame of your CraftBot should be approx. 1 mm (0.04 inches).



11. Open the door carefully (the hinges should not shift!) and tighten both grub screw on the hinge gripping the CraftBot's frame. These screws point towards the inside of the CraftBot.



12. Mount the lower hinge as well, then tighten the grub screws.



13. CraftBot with properly installed door:



If you have any questions or problems with installing the door, please don't hesitate to contact us. support@craftunique.com